




AQB/SEP/AQD Parts List




AQB



SEP



AQD Size 12



AQD Size 16-24

Parts No.	Description				
	Size 24	Size 30	Size 36	Size 42	Size 48
1	Baffle			Baffle	
2	Driver Sheave			Driver Sheave	
3	Belt Set			Belt Set	
4	Driven Sheave			Driven Sheave	
5	Upper Post (4)	Upper Post (8)		Upper Post (8)	
6	Shaft			Shaft	
7	Birdscreen			Birdscreen	
8	Power Assembly			Power Assembly	
9	3/8" Nut (4)			3/8" Nut (8)	
10	3/8" Bolt (4)			3/8" Bolt (8)	
11	Bearings (2)			Bearings (2)	
12	Cast Propeller Assembly			Cast Propeller Assembly	
13	Motor Plate			Motor Plate	
14	Base			Base	
15	Venturi			Venturi	
16	Lower Posts(4)			Lower Post (4)	
17	Baffle Brake			Baffle Brake	
18	Isolators (4)			Isolators (4)	
19	Motor			Motor	

Parts No.	Description			
	Size 12	Size 16	Size 20	Size 24
1	Baffle		Baffle	
2	5/16" Bolt (12)		5/16" Bolt (12)	
3	Upper Post (4)		Upper Post (4)	
4	Birdscreen		Birdscreen	
5	—		— Lower Post (4)	
6	5/16" Nut (4)		5/16" Nut (4)	
7	Motor		Motor	
8	Propeller		Propeller	
9	— Motor Plate		Motor Plate	
10	Base		Base	
11	Venturi		Venturi	
12	— Isolator (4)		Isolator (4)	
13	Power Assembly		Power Assembly	