

Belt Drive with Coil Option Parts List - ERV 1500 through ERV- 10000

Part Number	Description	Quantity
1	Supply Blower Access Door	1
2	Coil Cover Panel	1
3	Fluid Coil Cover	Varies
4	Fluid Coil Grommet - 1-7/8 I.D.	Varies
5	DX Coil Access Door	1
6	Condensate Drain Pipe	1
7	DX Coil Cover	Varies
8	DX Coil Grommet - 1-5/8 I.D.	Varies
9	Cassette Access Door	1
10	Front Panel (Not Shown)	1
11	Preheater (Optional)	1
12	Filter Access Door	1
13	Cooling Coil (DX or CW) - Optional	(1) Size 1500-3500, (2) Size 4500 & Up
14	Heating Coil (HW or Electric) - Optional	(1) Size 1500-3500, (2) Size 4500 & Up, (1) Electric
15	Secondary Block Off Panel	1
16	Drain Pan (Not Shown)	1 (Supplied with Cooling Coil)
17	Topcap (Not Shown)	2

Notes:

Parts List

The ERV and the ERV with Coils Option share many of the same parts. If the part is not called out here, then refer to the Belt Drive Parts List on the preceding page.

Filters

The ERV and the ERV with Coils Option use the same filters. For filter sizes refer to the filter size table on the preceding page.

