


# SRSH-B Parts List



Hood shown open for clarity

Part No.	SRSH-B Parts Description	Part No.	SRSH-B Parts Description
1	Hood Assembly	9	Power Assembly
2	Locking Hasp	10	Bearings (2)
3	Door Stay Rail (2)	11	Shaft
4	Door Stay Strut (2)	12	Driven Sheave
5	Base Assembly with Skirt	13	Drive Sheave
6	Down Conduit	14	Belt
7	Motor Tray	15	Wheel (not shown)
8	Isolator (4)		